


Step 1: open the tool.

TIME file decompression



Step 2: put  into the SD card of the clock camera, so need insert TF card into clock camera before do this.

Step 3: double-click the tool TIME files,  came out a file,



and then pull out the USB interface, and then automatically red light flash three times, modified TIME will automatically upgrade to the system. Note: this is the time synchronization, This is the time synchronization, if necessary, you can modify good computer time before setting time.